


Montageanleitung Schiene

- Die Abdeckwinkel (A) von der Deckenschiene abschrauben, die Deckenschiene an der Decke montieren und elektrisch anschließen.
- Die Kabel der Leuchten auf die gewünschte Länge kürzen.
- Die Kabel durch den Schlitz der Schiene und die Stellringe (B) führen und an den Lüsterklemmen anschließen.
- Die Madenschraube im Stellring festziehen, jedoch nicht zu sehr, um das Kabel nicht zu beschädigen.
- Am Schluss die Abdeckwinkel wieder mit den Inbusschrauben befestigen.



Assembling Instruction Track

- Screw off the cover-angle (A) from the ceiling-track, assemble the track to the ceiling and connect it electrically.
- Shorten the cables of the lamps to the desired position.
- Lead the cable through the slit of the track and the adjusting rings (B) and connect it to the connector.
- Fasten the grub-screw to the adjusting ring, but not too tight in order to prevent the cable from damage.
- Finally fix the cover-angle again with the Allen-screws.

Allgemeine Hinweise

Deckenschiene für Hängeleuchten 230 V/120 V
mit Phasen- und Phasenabschrittdimmer dimmbar
folgende Dimmer können wir empfehlen:

Gira 030700
Jung 225 TDE
Berker 2874

Montagezubehör:

4 Dübel
4 Schrauben
1 Inbusschlüssel

1180 mm lange Schiene
1560 mm lange Schiene
1940 mm lange Schiene

Achtung:

Leuchten sind nur vom Fachmann zu installieren!

General Notes

ceiling track for suspended lamp: 230 V / 120 V
230 V version dimmable with leading
edge-and trailing-edge-dimmers
following dimmers can be recommended:

Gira 030700
Jung 225 TDE
Berker 2874

Assembling accessories:

4 dowels
4 screws
1 Allen-type-wrench

1180 mm long track
1560 mm long track
1940 mm long track

Attention:

The lamps have to be installed by an electrician only!

ANTA.



ANTA Leuchten GmbH
www.anta.de
D- 22869 Schenefeld
Stand:Februar 2017

**Deckenschiene
Ceiling track**